

Prep for Coating: Stripping Floors

Stripping existing products from the floors before applying xGen Coatings is the key to a successful application of our products. Please ensure that the following procedures are followed for stripping floors BEFORE application of new coatings begins.

TOOLS REQUIRED FOR CLEANING

- Doodlebug
- Brushes
- Applicable stripper compound
- Mop Bucket
- Mop
- Scrapers
- All tools used for cleaning

STRIPPING PROCESS

- Check the label for mixing/application instructions and dwell time. Check for results as dwell time needed may need to be longer than stated on the directions.
- The process may require multiple applications and spot-treating as necessary.
- After all coating is removed, use the *Prep For Coating: Cleaning Floors* process EXCEPT: When finished cleaning with extractor, take a PH strip and lay in water in floor at 5 different points (all 4 corners and the middle of the area). Notice the color scale on the strip and compare with instructions on box. You need a pH level of no lower than 7 and no higher than an 8.5.